



CELL-KLEEN™

Flexo Wash & Ultrasonic Cleaner

FEATURES/BENEFITS

Features

Highly concentrated

No SARA Title III Section 313 reportables

One product cleans all:

- Anilox system & rolls
- Top & bottom press rolls
- Dies
- Press frames & machinery
- Floors

Biodegradable

No fire or flash point

Free rinsing

Benefits

Extremely cost effective

Reduces cleanup time

Reduced reporting

Versatile

Pleasant to work with

Leaves no film or residue after rinsing

Cell-Kleen is available in 6 gallon pails, 55 gallon drums, totes and bulk deliveries.

Description

Cell-Kleen is a concentrated, low-foaming liquid alkaline cleaner, formulated for fast removal of water-based inks, grease, oil and grime in the paper converting and flexographic printing industries.

Directions for Use

Anilox System: Add 1/2 to 1 gallon of concentrated product to a 5 gallon ink pot filled with clean water and flush the system for 15 to 30 minutes. Rinse with clean water. Some scrubbing with a stainless steel or brass brush may be necessary to remove deeply embedded inks or other soils from the anilox roll.

General Press and Die Cleaning: Dilute concentrate with 5 to 10 parts water to clean dies, press frames and press rolls. Wipe or spray on, wipe off with a clean damp cloth.

Ultrasonic Cleaning: Dilute concentrate with 5 to 10 parts water in an ultrasonic cleaner, rinse the roll with water after cleaning is completed. *Important: Always consult your equipment manufacturer prior to cleaning. Misuse of equipment can result in roll damage.*

Floors: Dilute concentrate with 5 to 10 parts water, apply with a clean mop or floor scrubber. Pick up the solution with a well wrung mop or wet vac.

IMPORTANT: Before using *Cell-Kleen*, always be sure to read and follow precautions and directions on the product container label and MSDS. (Mar04)